

FIG. 2

3/17

121




FIG. 3




FIG. 4




FIG. 5

6/17

0900391.070601  
"T09020" T6E00660





FIG. 6






FIG. 8



9/17

500




FIG. 9




FIG. 10




FIG. 11




FIG. 12




FIG. 13





FIG. 14



**FIG. 16**








FIG. 18

SELECTIONS FROM  
MENU OR SCREEN

QUICK TIP: PRESS  
ANIMATION TO HEAR AND  
SEE DEMO

ANIMATION

MORE INFORMATION

VOICE

AUDIO SYSTEM RADIO CASSETTE CD VIDEO TV WEATHER BAND

RADIO STATIONS: XX LOS ANGELES, XX SANTA ANA STATIONS

SAVE AREA SETTINGS YES NO

SELECTION BEING PLAYED:

XX SONG, XX ALBUM 1245

OTHER

1247 1249

YOU ARE  
LISTENING  
TO:

AM107.8

1271

AM103.5

FM100.7

1273

10 COUNTRY: FM102.9 AM103.5

1275

☆ AM79.00

8 TALK/NEWS: FM89.9 FM91.2 AM98.6 AM10.70

5 ROCK: FM89.3 FM98.1

FM102.7 FM107.90

AM990

1277

2 CLASSIC: FM91.4 FM96.4

SET FOR: (DRIVER) PASSENGER 1 2 3 4 5

ON OFF VOLUME CONTROL

FADER CONTROLS FRONT LEFT RIGHT  
BACK LEFT RIGHT

MOVE SPEAKERS FOR

DESIRED SOUND

EFFECTS

PRESSEFFECT THEN

SPEAKER

ROCK

SURROUND

MOVIE

ETC.

1255

1251

1253

1257

YOU  
ARE  
HERE

QUICK TIP: SCROLL FOR  
XX MORE STATIONS  
USE MOUSE CONTROLS  
OR PRESS TO SELECT

QUICK TIP: ANTENNA  
IS ACTIVATED BY  
RADIO AND TELEPHONE,  
BOTH MUST BE  
SWITCHED OFF TO  
LOWER ANTENNA

STEREO

DOLBY

DIGITAL  
ENCODED

SMART AUDIO

AUTO RADIO

RESTORE SETTINGS

MORE INFORMATION

SAVE PREFERENCES

1207

1205